

## Operating Instructions for Linear Feeders

SLA 175 – 250

SLA 400 – 400

SLA 400 – 600

SLA 400 – 800

SLA 400 – 1000

# Table of Contents

1.	Technical data.....	4
2.	Safety Information.....	6
2.1.	Applicable directives and standards.....	8
3.	Design and functional description of linear feeder.....	8
4.	Shipment and installation.....	9
4.1.	Shipping and handling.....	9
4.2.	Installation.....	10
5.	Commissioning.....	10
5.1.	Tuning.....	11
5.1.1.	Setting the desired feeding speed.....	11
5.1.2.	Adjusting the desired feeding behaviour / synchronism of the linear feed rail.....	13
6.	Feed rail design rules.....	16
7.	Maintenance.....	17
8.	Spare parts and customer service.....	17
9.	What if... (Advice on troubleshooting).....	18



## Declaration of Incorporation

according to Machinery Directive 2006/42/EC

We,  
Company

**Rhein-Nadel Automation GmbH**  
Reichsweg 19-23  
52068 Aachen  
Germany

herewith declare under our sole responsibility that with regard to the following product:

Machine designation: (function)	Linear feeder
Type designation:	SL(...) GL(...)
Serial number	10865660 0001 2500000 0001

all relevant essential safety and health requirements of Directive 2006/42/EC have been fulfilled up to the battery limits.

The product to which this declaration refers is furthermore in conformity with following directives and standards or other regulations:

2006/42/EC	Machinery
2006/95/EC	Low Voltage
2014/30/EU	Electromagnetic Compatibility

EN 614-1	2006+A1:2009	EN ISO 13857	2008
EN 619	2002+A1:2010	EN ISO 14120	2015
EN 620	2002+A1:2010	EN 60204-1	2006
EN ISO 12100		2010	

The relevant technical documentation has been compiled in accordance with Annex VII B of the Machinery Directive and on request, such documentation will be transmitted to the competent authorities in hard copy.

Nico Altmeyer, Rhein-Nadel Automation GmbH, Reichsweg 19-23, 52068 Aachen

**(Name and address of person authorised to compile the relevant technical documentation)**

**Notice:** This machine must not be put into service until the complete system into which it will be incorporated has been declared to be in conformance with the provisions of the Directive.

### Signatory information

Name: Dr. Hensen

Given name: Tobias

Function: Managing Director

Germany  
Aachen,

Place and date

Signature

# 1. Technical data



**Notice:**


All linear feeders listed in this table shall be operated only in conjunction with an RNA controller and with a mains voltage of 230 V / 50 Hz. For special voltages and frequencies please refer to the separate data sheet.



**Notice:**


Linear feeders of type SLA are '-2' devices with a vibration frequency of 100 Hz.

**Pin assignment**



M20 gland

grey-2      100 Hz vibration frequency  
 black-1     50 Hz vibration frequency  
 Metal EMC gland for  
 frequency-controlled systems



**Mode of operation**

Vibration frequency  
 With jumper: 100 Hz  
 Without jumper: 50 Hz

Coding in connector

## Linear feeder type SLA 175

Linear Feeder Type	SLA175-250
Dimensions L x W <sup>2)</sup> x H (mm)	305x70x97
Weight	3.3
Degree of protection	IP54
Connecting cable length (m)	1.5
Power input <sup>1)</sup> (VA)	16
Current <sup>1)</sup> (A)	70 mA
Nominal magnet voltage <sup>1)</sup> / frequency (V / Hz)	200/50
Number of magnets	1
Magnet type	WZAW010
Magnet colour	black
Air gap (mm)	0.8
Vibration frequency in Hz/min <sup>-1</sup>	100 // 6000
Number of spring packs	2
Standard spring configuration of all spring packs	2x neutral springs 1.5mm / 4x 0.75mm / 4x 1.0mm
Spring dimensions (mm) length (borehole gauge) x width	44.3 (35) x 26.7 (12)
Spring thickness (mm)	0.75, 1.0 and 1.5
Property classes of spring fastening bolts	8.8
Tightening torque of spring fastening bolts	3 Nm
Max. weight of vibrating units, linear rail and mounting parts	1.0 - 1.7 kg
Maximum rail length (mm)	375
Maximum part weight of all parts present on the linear feeder	500 g

## Linear feeder type SLA 400

Linear Feeder Type	SLA 400 - 400
Dimensions L x W <sup>2)</sup> x H (mm)	511 x 102 x 168
Weight	11
Degree of protection	IP 54
Connecting cable length (m)	1.5
Power input <sup>1)</sup> (VA)	120
Current <sup>1)</sup> (A)	600 mA
Nominal magnet voltage <sup>1)</sup> / frequency (V / Hz)	200 / 50
Number of magnets	1
Magnet type	WZAW 040
Magnet colour	black
Air gap (mm)	1.2
Vibration frequency in Hz/min <sup>-1</sup>	100 / 6.000
Number of spring packs	2
Standard spring configuration of all spring packs	2x neutral springs 3mm / 2x 3mm / 2x 3.5mm
Spring dimensions (mm) length (borehole gauge) x width	70 (56) x 40 (18)
Spring thickness (mm)	2.0, 3.0 and 3.5
Property classes of spring fastening bolts	8.8
Tightening torque of spring fastening bolts	12 Nm
Max. weight of vibrating units, linear rail and mounting parts	4 – 5kg
Maximum rail length (mm)	650
Maximum part weight of all parts present on the linear feeder	1 kg

SLA 400 - 600	SLA 400 - 800	SLA 400 - 1000
711 x 102 x 168	911 x 102 x 168	1111 x 102 x 168
14	18.5	22.5
IP 54	IP 54	IP 54
1.5	1.5	1.5
120	120	120
600 mA	600 mA	600 mA
200 / 50	200 / 50	200 / 50
1	1	1
WZAW 040	WZAW 040	WZAW 040
black	black	black
1.2	1.2	1.2
100 / 6.000	100 / 6.000	100 / 6.000
2	4	4
2x neutral springs 3mm / 4x 3mm	4x neutral springs 3mm / 16x 2mm	4x neutral springs 3mm / 8x 3mm
70 (56) x 40 (18)	70 (56) x 40 (18)	70 (56) x 40 (18)
2.0, 3.0 and 3.5	2.0, 3.0 and 3.5	2.0, 3.0 and 3.5
8.8	8.8	8.8
12 Nm	12 Nm	12 Nm
5 - 6.5 kg	6 - 8 kg	8 - 10 kg
850	1050	1250
1 kg	1 kg	1 kg

<sup>1)</sup> For special connections (voltage / frequency) see rating plate on the magnet

<sup>2)</sup> Width indication for version b (= breit/wide)

## 2. Safety Information

We have taken great care in design and manufacture of our linear feeder in order to ensure smooth and safe operation. You, too, can make an important contribution towards safety at work. We therefore ask you to read the brief operating instructions completely prior to commissioning the system. Observe the safety directives at all times!

Make sure that all persons working with or on the equipment also read the following safety directives carefully and follow them!

These Operating Instructions only apply to the equipment types indicated on the cover page.



### Notice:

This symbol indicates useful tips for operation of your linear feeder.



### Attention:

This warning triangle indicates safety notices. Non-observance of such warnings may cause serious injury or even death.

### Machine hazards

- Hazards arise mainly from the electrical components of the linear feeder. If the linear feeder comes into contact with moisture or liquids there is risk of electric shock.
- Make sure that protective earthing of the power supply system is in perfect condition!

## Intended use

The intended use of the linear feeder is the driving of feed rails. They serve for linear transfer as well as correctly oriented and metered supply of bulk parts.

Intended use also includes observance of the operating instructions and compliance with the maintenance rules.

For the technical data of your linear feeder please refer to 'Technical Data' in Section 1. Make sure that the rating data of the linear feeder, control system and power supply are compatible.



### Notice

Operate the linear feeder in perfect condition only.

---

Never operate the linear feeder in areas subject to explosion hazards or in wet areas.

Operate the linear feeder only in the configuration of drive unit, control unit and vibratory system agreed with the manufacturer.

The linear feeder must never be subjected to any loads other than the parts for which this special type has been rated and dimensioned.

---



### Attention:

It is strictly forbidden to disable any guards or safety devices!

---

## Equipment user's duties

- Observe the directives given in the operating instructions for any kind of work (operation, maintenance, repairs, etc.).
  - Refrain from any working practice that affects the safety at the linear feeder.
  - Make sure that only authorised personnel work at the linear feeder.
  - Give immediate notice to the management of any changes that have occurred on the linear feeder affecting safety.
- 



### Attention:

**The linear feeder must be installed, put into operation and maintained by professional personnel only.** Observe the legally binding provisions for the qualifications of qualified electrical workers and instructed workers as defined by standards IEC 364 and DIN VDE 0105, part 1.

---



### Caution: Electromagnetic field

Magnetic fields may affect a cardiac pacemaker. Therefore, persons wearing a cardiac pacemaker are recommended to keep a distance of at least 25 cm.

---

## Noise emission

The noise level at the place of use depends on the complete line into which the hopper will be incorporated and on the material to be conveyed. For this reason, sound pressure levels in accordance with the 'Machinery' directive can only be determined at the place of installation. If the noise level at the place of use exceeds the permissible, sound-insulating hoods can be installed which we can offer on request.

## 2.1. Applicable directives and standards

The linear feeder has been manufactured in accordance with the following directives:


2006/42/EC	Machinery Directive
2014/35/EU	Low Voltage Directive
2014/30/EU	Electromagnetic Compatibility Directive

We assume that our product will be incorporated into a stationary machine.

The applicable standards are specified in the Declaration of Incorporation (according to Annex II B of the Machinery Directive).

## 3. Design and functional description of linear feeder

Intended use of linear feeders is the feeding of parts. The driving force is provided by an electromagnetic coil. The figure below is a schematic representation of a linear feeder:



- A Feed rail and vibrating mass
- B Parts handled
- C Spring pack
- D Drive magnet
- E Armature
- F Exciter mass
- G Framework
- H Counterweight for counter mass
- I Counterweight for vibrating unit
- K Balancing weight

The linear feeder belongs to the family of vibratory feeders, but produces a straight-line motion. Electromagnetic oscillations are converted into mechanical vibrations that are used for conveying the parts. When alternating current is applied to the magnet which is rigidly connected to counter mass F, the magnet exerts a force which attracts and releases armature E in synchronism with the mains frequency. Within each period of the 50 Hz A.C. mains supply, the magnet will achieve its maximum power of attraction twice as this force builds up independently of the current flow direction. Accordingly, the vibration frequency is 100 Hz in this case.

A linear feeder is a resonant system (spring-mass system). As a result, its factory set-up will rarely meet your on-site requirements. Section 5 describes in detail how you can adapt the feeder to your specific requirements.

The linear feeder is controlled by a low-loss ESR 2000 type electronic control unit. The linear feeder control unit is supplied loose (not installed). The controller has a 5-pin connector on its front panel for connection to the linear feeder.

For assignment of the socket pins refer to the technical data in Section 1.



### Notice:

For comprehensive information on the full range of control devices please refer to the 'Control Units' operating instructions.

All control units have two essential operating elements:

- The **power switch** is used to energize and de-energize the linear feeder.
- The **membrane keypad** can be used to set the feed rate of the system.

## 4. Shipment and installation

### 4.1. Shipping and handling

#### Shipment ex works

The linear feeders are delivered ex works in a box or crate.

#### On-site moving

The weight of the linear feeder depends on its dimensions and motor rating. Please refer to the shipping documents for the weight of your specific equipment.



#### Attention

Check all guards when unpacking. Replace any damaged parts before commissioning!



#### Attention

For lifting the feeders be sure to use only sufficiently dimensioned vehicles, ropes, chains and sling gear.



#### Attention

Handling operations to be carried out only by employees who are capable of performing such work due to their own knowledge and experience in this field.



#### Warning

Warning against suspended loads



#### Notice:

Take care that the linear feeder cannot collide with other objects during handling operations. **The locking pins also serve as shipping braces.**

For the weight of the linear feeder please refer to the table titled 'Technical Data' in Section 1.



#### Notes on shipping braces Linear feeder

Prior to commissioning, remove the shipping braces marked black and yellow.

## 4.2. Installation




### Attention

The linear feeder is intended to complete / to be incorporated into a complete system. Do not operate the machine before safe completion/incorporation by the user.

The linear feeder should be mounted on a stable substructure (available as an accessory) at the point of use. This substructure must be dimensioned such as to ensure that it does NOT vibrate during operation. Fix the linear feeder to the supporting columns (part G in overview drawing of Section 3) from below. Following table gives an overview of the drilling data for the drive units used:

Linear feeder type	Length X in mm	Width Y in mm	Shock absorber thread
SLA 175 - 250	180	58	M6
SLA 400 - 400	250	82	M6
SLA 400 - 600	400	82	M6
SLA 400 - 800	600	82	M6
SLA 400 - 1000	800	82	M6

Table: Drilling data



Make sure that the linear feeder cannot touch other devices during operation.

For further details on the control unit (drilling template, etc.), please refer to the separate operating instructions manual of the control unit.

## 5. Commissioning



### Attention:

Make sure that the machine frame (rack, substructure, etc.) is connected to the protective earth conductor (PE). Protective earthing has to be provided by user as necessary.



### Attention:

It is imperative that the vibrating drive be connected to the equipotential bonding system of the overall equipment before commissioning. The adaptation points are marked with earth symbols.

See also: DIN EN 60204 / VDE 0100-540



### Attention:

Electrical connection of the linear feeder must be made by trained professional electricians only! When making any change to the electrical connection make absolutely sure that the 'Control Units' operating instructions are duly observed.

Verify that

- the linear feeder is arranged freely without contact to any solid body
- the linear rail is properly aligned and firmly bolted in place
- the linear feeder connecting cable is plugged into the control unit.
- The available electricity supply (frequency, voltage, power) must correspond to the connection data of the control system (see rating plate on the control unit).  
Plug the cable of the control unit into a power socket and operate the power switch to energize the control unit.

**Notice:**

For linear feeders that are supplied as a completely set-up system the optimum feed rate has been factory-set.

Optimum tuning is achieved when the desired feed rate is obtained with a control unit setting of 80 %. In case of larger deviations (> +/- 15%) you should re-tune the system mechanically.

## 5.1. Tuning

The spring configuration of the linear feeder is dimensioned such that no tuning of the springs is required for the specified rail weights. The feeding speed is controlled via the driving frequency (which must be above than the natural frequency of the vibration system).


**Notice:**

As a first step, balance the masses by adjusting the weight of the counter mass to match the weight of the linear rail (vibrating mass).

### 5.1.1. Setting the desired feeding speed

If the desired feeding speed cannot be achieved with the standard spring configuration, you must remove or add springs uniformly on both sides of the spring pack, using a spring stacking device.

The following graph shows the resonance curve of a linear feeder:



A	Feed rate
B	Desired feeder speed
C	Resonance frequency of the system
D	Resonance curve
E	Spring force (number of springs) increasing

**Notice**

The resonance frequency of the linear feeder must not coincide with the mains frequency (driving frequency). In most cases, it should be lower than this driving frequency.

When changing springs, take into account that leaves of different thicknesses have different spring forces. As the spring force increases to the square of spring thickness, please note the following examples:


- 0.75 mm spring thickness = 0.56 spring force
- 1.0 mm spring thickness = 1.00 spring force
- 1.5 mm spring thickness = 2.25 spring force
- 2.0 mm spring thickness = 4.00 spring force
- 3.0 mm spring thickness = 9.00 spring force
- 3.5 mm spring thickness = 12.25 spring force

One 2.00-mm thick leaf spring produces approximately the same spring force as four 1.00 mm thick leaf springs. It is always recommended, therefore, to perform the final adjustment / fine-tuning with thin leaf springs.

**Notice:**

Changing the counter mass or the vibrating mass (by adding or removing counterweights or add-on weights) will change the conveying speed or the natural frequency, respectively, of the linear feeder. It may become necessary to change the driving frequency. The driving frequency should be between 95 and 105 Hz.

It can be assumed that if the masses of vibrating and counter mass are equal the amplitudes of the two masses will be equal, too. If this is not the case with the linear rail attached the difference in speed must be compensated by adding or removing weights. For a system with sub-critical tuning (natural frequency is below the driving frequency of current) the amplitude can be decreased by mounting weights.

**Changing the spring configuration on SLA 175 type linear feeders**

Remove the 4 upper lateral spring fastening screws 'L1' (M4 x 10 DIN 912). Now you can lift out the complete vibratory unit, with feed rail attached. The linear feeder is now open to the top. Insert the  $\varnothing 4$  mm lock pins supplied into the bottom holes marked with 'M'.

This is to keep the framework properly aligned to the counter mass. Remove the desired spring pack by removing the lower lateral spring fastening screws 'L2' (M4 x 10 DIN 912) and shaft 'C' (SW 4).


When working on the dismantled spring pack use a spring stacking device to ensure that the individual components of the spring pack stay in position. Screw the spring pack into the device and clamp the device into a vise. Always add or remove springs symmetrically to the axis, i.e. always add or remove 2 springs at a time. Insert spacers between the individual springs. Then tighten the spring fastening screws to a torque of 3.5 Nm. Now insert the entire spring pack into the substructure. Insert the lower spring fastening screws, mount the shaft and put the vibratory unit back in place. For alignment of the vibratory unit insert the pins supplied into the upper holes marked with 'M'. Now you can tighten the individual spring packs at the desired spring angle.

**Notice:**

Tighten the upper and lower spring fastening screws 'L1 / L2' to a torque of 3.5 Nm. Make sure to slightly tighten **shafts 'O' carefully** to a torque of 2 Nm only.

The locking pins supplied serve for alignment of the components and as shipping braces. Take care to remove these pins before starting the linear feeder.

## Changing the spring configuration on SLA 400 type linear feeders



Remove the 4 upper lateral spring fastening screws 'L1' (M6 x 14 DIN 912). Now you can lift out the complete vibratory unit, with feed rail attached. The linear feeder is now open to the top. Insert the  $\varnothing 6$  mm lock pins supplied into the bottom holes marked with 'M'. This is to keep the framework properly aligned to the counter mass. Remove the desired spring pack by removing the lower lateral spring fastening screws 'L2' (M6 x 16 DIN 912) and shaft 'C' (SW 5).

When working on the dismantled spring pack use a spring stacking device to ensure that the individual components of the spring pack stay in position. Screw the spring pack into the device and clamp the device into a vise. Always add or remove springs symmetrically to the axis, i.e. always add or remove 2 springs at a time. Insert spacers between the individual springs. Then tighten the spring fastening screws to a torque of 12 Nm. Now insert the entire spring pack into the substructure. Insert the lower spring fastening screws, mount the shaft and put the vibratory unit back in place. For alignment of the vibratory unit insert the lock pins supplied into the top holes marked 'M'. Now you can tighten the individual spring packs at the desired spring angle.



### Notice:

Tighten the upper and lower spring fastening screws 'L1 / L2' to a torque of 12 Nm. Make sure to slightly tighten **shafts 'O' carefully** to a torque of 3.5 Nm only.


The locking pins supplied serve for alignment of the components and as shipping braces. Take care to remove these pins before starting the linear feeder.

### 5.1.2. Adjusting the desired feeding behaviour / synchronism of the linear feed rail

For a linear feed rail to operate smoothly and in synchronism, the spring angle must be set to be identical to the centre-of-gravity angle. The centre-of-gravity angle is determined by the locations of the centres of gravity of the vibrating mass and of the counter mass.


In the drawing the centres of gravity of vibrating mass and counter mass are marked by circles.

**Example based on a centre-of-gravity angle of 12.5 deg.**




*Spring angle equal to centre-of-gravity angle*

The spring force is directed to attack exactly at the vibratory unit's centre of gravity.  
**Result:** the height amplitude is equal on the run-in and run-out sides.



*Spring angle larger than centre-of-gravity angle*

The spring force is directed to attack ahead of the vibratory unit's centre of gravity.  
**Result:** the height amplitude on the run-in side is greater than on the run-out side.



*Spring angle smaller than centre-of-gravity angle*

The spring force is directed to attack behind the vibratory unit's centre of gravity.  
**Result:** the height amplitude on the run-in side is smaller than on the run-out side.

If the two angles are not identical, the feed rail will not run smoothly.

You can adjust the centres of gravity or spring angles, respectively, by the following means:

- adding or removing counterweight 'H'
- adding or removing additional counterweight in the vibratory unit's run-out area 'I'
- dimensioning the rail length and height such as to create an adjustable centre of gravity at the vibrating mass
- dimensioning the rail weight according to specifications such as to ensure equal weight of vibrating mass and counter mass
- adjusting the spring angle to match the centre-of-gravity angle.

On linear feeders of types SLA 175 and SLA 400 , the spring angle can be adjusted between 5 and 25 degrees. If the centre-of-gravity angle lies outside this range, the rail cannot run smoothly and in synchronism. It is necessary in that case to adapt the centres of gravity of the reaction mass and vibrating mass through the measures listed above.

### Spring angle adjustment

In order to adjust the spring angle, fix the position of the vibratory unit relative to the counter mass. (see section 5.1.1 'Changing the spring configuration on linear feeders'). For this, insert the four locking pins supplied. Then loosen the four lateral spring fastening screws ('L1' + 'L2'). Now adjust the spring packs as uniformly as possible (see also section 5.1.2). Then re-tighten the spring fastening screws to the specified tightening torque (see Section 1, 'Technical Data') and remove the locking pins.

### Adjusting the magnet air gap

The factory setting of the air gap between armature and coil is indicated in the 'Technical Data' in Section 1.

Adjustment of this air gap can be performed from the outside without dismantling any components. Slightly slacken the two exterior armature fastening screws 'N'. Insert a wire (0.8 / 1.2 mm in diameter, 80 mm long) in each of the two holes in the vibratory unit's supporting member. Make sure that the wire does not enter the groove of the armature. Adjust the air gap (0.8 / 1.2 mm, see section 1, 'Technical data') by pressing down the two armature fastening screws against the direction of travel, then tightening them.



**Notice:**

If the rotary knob on the controller is set to 100% and the air gap correctly set, the magnet must not hit the armature upon power-on. If it does, proceed as described under section 5.2. (removal of springs)

---

### Objective of the tuning procedure:

When the desired feeding speed is obtained at a controller setting of 80%, it must increase when a weighting plate is removed.



**Notice:**

Make sure that the number of springs per spring pack will not deviate by more than 1 spring. Also make sure that the springs are packed symmetrically to the bearing spring.

---

## 6. Feed rail design rules

As the rail section (vibratory mass) and the counter mass of linear feeder type SLA must be equal, the weight of the feed rail must be considered during rail design.

Rail projections beyond the vibratory unit of max. 50 mm at the entry (25 mm for SLA 175) and max. 200 mm at the exit (100 mm for SLA 175) can be realized, however, a rail projection at the exit should always be larger than that at the entry. (Observe a ratio of 1/3 to 2/3.)

In order to obtain resistance to lateral torsion use a one-piece support plate / adapter plate for the rail.

Recommended adapter plate thicknesses for SLA linear feeders in mm and rail weight in kg

Size	Adapter plate / aluminium	Rail weight of complete rail
<b>SLA175-250</b>	10	1.0 - 1.7 kg
<b>SLA400-400</b>	12	4.0 - 5.0 kg
<b>SLA400-600</b>	12	5.0 - 6.5 kg
<b>SLA400-800</b>	12	6.0 - 8.0 kg
<b>SLA400-1000</b>	12	8.0 - 10.0 kg

By changing the profiles of the linear feeder from the left to the right and vice versa you can obtain the narrow 'S' version or the wide 'B' version.

The higher the feeding speed the higher the clearance should be made between top of part handled and bottom of feed rail cover. This clearance should be set to the largest acceptable value. When mounting the feed rail observe the following:

- Mount it closely above the top of the vibratory unit.
- Locate as precisely as possible on the aluminium profile center.
- Use stable rigid screws (M5 as a minimum). For type SLA 175 use M4 for the adapter plate.
- In order to obtain a higher feeding speed the linear feeder can be installed with a slight inclination in feeding direction (about 3 to 5 degrees).
- Never use any loose or hinged covers not firmly bolted in place.

The feed rail may be made up of several short sections to be joined and screwed in place on the adapter plate. At the entry, flat chamfers assist part transfer from one feed rail section to another.

The split design of several sections is recommended especially for hardened or case-hardened rails (made for low distortion).

Lightweighting of feed rails can be realized by using aluminium strips or profiles. The required wear resistance can then be obtained by segments of hardened spring steel strip bolted in or on.

## 7. Maintenance

Linear feeders basically require no maintenance. They should be cleaned when soiled or after coming into contact with liquids.

- Before starting such work be sure to pull the mains plug.
- Clean the inside of the linear feeder (dismount components as necessary), and in particular the air gap of the coil.
- After remounting the components and plugging in the mains plug the linear feeder is again ready for operation.



### Attention

For installation, maintenance and repair work all poles of the power supply must be disconnected from the linear feeder in compliance with VDE provisions. Any work on electrical equipment of the linear feeder shall be carried out exclusively by a professional electrician, or by instructed persons (see chapter 2) working under the direction and supervision of a professional electrician, according to electrotechnical rules.

---



### Attention

Be careful when working on linear feeders! The magnets can get hot during operation. Therefore let magnets cool down before working on them. If this is not possible, take suitable protective measures such as the use of gloves.

---



### Attention

If any guards have been removed, be sure to fit them back in place!

---

## 8. Spare parts and customer service

For efficient work on the linear feeders several tools are required, among others the spring stacking device, the locking pins and the coil gap gauge.

As the linear feeder is designed for a long service life, spare parts are not required frequently.

Should a defect occur nonetheless, it mostly concerns the rubber bearings or magnets.

When ordering new parts, please specify the device type (see rating plate), the spare part designation (with article code if available) and the quantity required.

For a list of Service Center addresses refer to the back cover page of this manual.

## 9. What if... (Advice on troubleshooting)



### **Attention:**

Only professional electricians are allowed to open the control unit or connector. Pull the mains plug before opening!

If the rail feeding speed or height amplitude is not uniform but rather higher at the exit than at the entry, this indicates that the spring angle is incorrectly set relative to the centre-of-gravity angle (see Section 5.2.2). In this case proceed as follows:

- Increase the spring angle on all spring packs.
- Fit additional weighting plates to counterweight 'H'.
- Install additional weight 'I' in the vibratory unit's supporting member.

If the rail feeding speed or height amplitude is not uniform but rather higher at the entry than at the exit, this indicates that the spring angle is incorrectly set relative to the centre-of-gravity angle (see Section 5.2.2). In this case proceed as follows:

- Decrease the spring angle on all spring packs.
- Remove additional weighting plates from counterweight 'H'.
- Remove additional weight 'I' from the vibratory unit's supporting member.

If the rail speed is uniform but the running behaviour is unstable and the parts jump too much between rail contact surface and top cover, this indicates that the centre-of-gravity angle and the set spring angle of the overall system and thus the height amplitude is too large. In this case proceed as follows:


- Change the centre-of-gravity angle (more 'flat') by attaching additional weighting plates to the counterweight 'H', installing an additional weight into the vibratory unit supporting member 'I' and making the feed rail lighter, if necessary.
- Adjust the spring angle to match the new centre-of-gravity angle.

If despite uniform height amplitude the running behaviour is unstable, especially with parts having a large contact area or oil-contaminated parts, this indicates that the centre-of-gravity angle and the set spring angle of the entire system is too small. The height amplitude is too small. This prevents the throwing motion and in case of oily parts the adhesive force is higher than the throwing force, i.e. the parts cannot take off. In this case proceed as follows:

- Change the centre-of-gravity angle (more 'steep') by removing weighting plates from counterweight 'H' and removing the additional weight from the vibratory unit supporting member 'I'.
- Adjust the spring angle to match the new centre-of-gravity angle.

If it is impossible to set-up the feed rail properly by following the above procedures and if lateral oscillation occurs or 'dead spots' are found in certain areas, then the stiffness of the rail is insufficient. The abutment joints move relative to one another or non-symmetric rail sections lead to non-uniform running behaviour. In this case proceed as follows:

- Mount lateral and transversal ribs in order to increase the section modulus and screw abutment joints together in overlapping fashion.
- Counter-balance non-symmetric sections by weights or replace by material lighter in weight.

Fault	Potential cause	Remedy
Linear feeder does not start on power up	<ul style="list-style-type: none"> <li>- Power switch off</li> <li>- Mains connector of control unit not plugged-in</li> <li>- Connecting cabled between linear feeder and control unit not plugged-in</li> <li>- Defective fuse in control unit</li> </ul>	<ul style="list-style-type: none"> <li>- Close power switch</li> <li>- Plug in the mains connector</li> <li>- Plug 5-pin connector into control unit</li> <li>- Replace fuse</li> </ul>
Only slight feeder vibration  	<ul style="list-style-type: none"> <li>- Controller setpoint too small</li> <li>- Shipping locks or braces not removed</li> <li>- Wrong vibration frequency</li> </ul> <p><b>Attention:</b>  <b>If you operate the linear feeders of type SLA 175 - 400 without having inserted the jumper in the 5-pin connector, there is a risk of damage to the controller and magnet!</b></p>	<ul style="list-style-type: none"> <li>- Set control unit to 80 %</li> <li>- Remove shipping locks or braces.</li> <li>- Check that coding in plug connector of the linear feeder is correct. (See rating plate and 'Technical Data' in Section 1.)</li> <li>- Vibration frequency between 95 Hz and 105 Hz when using a frequency controller.</li> </ul>
The linear feeder no longer meets the required feed rate after prolonged operation.	<ul style="list-style-type: none"> <li>- Fixing screws of linear rail have come loose.</li> <li>- Screws of one or more spring packs have come loose.</li> <li>- Coil-to-armature air gap has gone out of adjustment</li> <li>- Vibratory unit displaced towards the counter mass</li> </ul>	<ul style="list-style-type: none"> <li>- Re-tighten the screws.</li> <li>- Tighten screws (for tightening torques see 'Technical Data' in Section 1).</li> <li>- Readjust the coil-to-armature air gap (for air gap size see 'Technical Data' in Section 1).</li> <li>- Re-adjust the vibratory unit (see Section 5.2.1).</li> </ul>
Linear feeder makes loud noises.	<ul style="list-style-type: none"> <li>- Foreign matter in air gap</li> </ul>	<ul style="list-style-type: none"> <li>- Stop linear feeder and remove foreign matter. Then check the coil-to-armature gap.</li> </ul>
Linear feeder cannot be tuned to a constant speed for longer periods of time.	<ul style="list-style-type: none"> <li>- The spring constant of the vibrating system has changed. The linear feeder operates close to the resonance point.</li> </ul>	<ul style="list-style-type: none"> <li>- Re-tune the linear feeder. Remove springs. See Section 5: Tuning</li> </ul>



### Headquarters

Rhein-Nadel Automation GmbH  
Reichsweg 19-23  
D-52068 Aachen  
Phone: +49 (0)241-5109-0  
E-mail: [vertrieb@RNA.de](mailto:vertrieb@RNA.de)  
[www.RNA.de](http://www.RNA.de)

### Further RNA group companies:



PSA Zuführtechnik GmbH  
Steinackerstraße 7  
D-74549 Wolpertshausen  
Phone: +49 (0)7904-94336-0  
E-mail: [info@psa-zt.de](mailto:info@psa-zt.de)  
[www.psa-zt.de](http://www.psa-zt.de)



RNA Automation Ltd.  
Unit C Castle Bromwich Business Park  
Tameside Drive Birmingham B35 7AG  
Great Britain  
Phone: +44 (0)121-749-2566  
E-Mail: [sales@rnaautomation.com](mailto:sales@rnaautomation.com)  
[www.rnaautomation.com](http://www.rnaautomation.com)



HSH Handling Systems AG  
Wangenstraße 96  
3360 Herzogenbuchsee  
Switzerland  
Phone: +41 (0)62-956 10-00  
E-mail: [info@handling-systems.ch](mailto:info@handling-systems.ch)  
[www.handling-systems.ch](http://www.handling-systems.ch)



RNA Vibrant S.A.  
Carrer de l'Energia  
08940 Cornellà de Llobregat (Barcelona)  
Spain  
Phone: +34 (0)93-377-7300  
E-mail: [info@vibrant-RNA.com](mailto:info@vibrant-RNA.com)  
[www.vibrant-RNA.com](http://www.vibrant-RNA.com)



RNA Digital Solutions GmbH  
Reichsweg 19-23  
D-52068 Aachen  
Phone: +49 (0)1515-99 28 255  
E-mail: [kontakt@rnadigital.de](mailto:kontakt@rnadigital.de)  
[www.designforfeeding.com](http://www.designforfeeding.com)  
[www.rnadigital.de](http://www.rnadigital.de)

### Further manufacturing sites of the RNA Group

#### Lüdenscheid site

Rhein-Nadel Automation GmbH  
Nottebohmstraße 57  
D-58511 Lüdenscheid  
Phone: +49 (0) 2351 -41744  
E-mail: [werk.luedenscheid@RNA.de](mailto:werk.luedenscheid@RNA.de)

#### Ergolding site

Rhein-Nadel Automation GmbH  
Ahornstraße 122  
D-84030 Ergolding  
Phone: +49 (0) 871 -72812  
E-mail: [werk.ergolding@RNA.de](mailto:werk.ergolding@RNA.de)

#### Remchingen site

Rhein-Nadel Automation GmbH  
Im Höldele 3  
D-75196 Remchingen-Wilferdingen  
Phone: +49 (0)7232-7355-558  
E-mail: [werk.remchingen@RNA.de](mailto:werk.remchingen@RNA.de)